

ENVIROALERT®



Wireless Temperature Accessory for EnviroAlert EA800-ip

- Transmission distance of 1,000' (305 m) line-of-sight.
- Set temperature high/low set points on EnviroAlert console.
- Do **NOT** put EA-WTS in freezer/cooler. Use wired sensor.

Specifications

| | |
|-----------------------|--|
| Sensing Range | 32° to 122° F (0° to 50° C) |
| Power Requirements | 2 - AA Alkaline Batteries or +12 VDC @ <=100mA |
| Battery Life | Alkaline up to 1 year (not included) |
| Unit Operating Range | 32° to 122° F (0° to 50° C) Non-condensing environment. |
| Frequency | 2.405 GHz - 2.480 GHz, 16 channels. See owner's manual for more information. |
| Transmission Distance | 1,000' (305m) line-of-sight |
| Weight | 0.25 lb (0.11 kg) |
| Dimensions | 3.67 x 2.65 x 1.17" (9.3 x 6.7 x 2.9 cm) |
| Mounting | Surface Mount |

Accessory for
EnviroAlert EA800-ip



Visit www.winland.com, call 800.635.4269 or email techsupport@winland.com to learn more.

